Continuous Ink Supply System Cartridges

COCOD Member of DOCOD



Instructions for Ink Cartridge Use:

- 1. During operation, ensure the large ink cartridge is either hung vertically or wall-mounted. Maintain the bottom of the large ink cartridge at approximately 19 centimeters above the lower edge of the print head.
- 2. For your first-time usage, close the valve on the continuous ink supply system by aligning it vertically with the ink tube. Use the ink cartridge maintenance tool to conduct a vacuum priming. Following this, open the valve to commence printing. If ink leakage occurs during operation, you can utilize this vacuum priming method and perform nozzle cleaning as needed.

Add: Building 2, NO. 27, Hejing Road, Liwan District, Guangzhou, China



DOCOD WEB SITE